

# Rain Director® control panel

- A. Control unit with 12 volt bus, microprocessors, control buttons and indicator lights
- B. 12 volt supply from wall-socket-mounted mains converter
- C. Leads from header tank sensors
- D. Flush solenoid valve. Direction of flow, downwards by gravity.
- E. Rainwater solenoid valve. Direction of flow, upwards, from pump in storage tank
- F. Mains water solenoid. Direction of flow, upwards, under mains pressure
- G. Manual mains water cock. Direction of flow, upwards, under mains pressure
- H. Control unit cover with aperture to show buttons and lights

